

<b>MCx 204</b>	<b>Read Present Position(REAL): _MCx204_ReadActualPosition_REAL</b>	
<b>Basic function</b>	Reads the present position of an axis.	
<b>Symbol</b>		
<b>File name</b>	Lib\FBL\omronlib\ PositionController \MCx\ _MCx204_ReadActualPosition_REAL10.cxf	
<b>Applicable models</b>	Motion Control Unit CPU Unit CX-Programmer	CS1W-MC221(-V1)/421(-V1) CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher CP1H Version 5.0 or higher
<b>Conditions for usage</b>	None	
<b>Function description</b>	<p>While Output enabled (Enable) is ON, the present position of the axis specified with Unit No. (UnitNo) and Axis No. (Axis) is cyclically read and output. Turning OFF Output enabled (Enable) will clear the present position to 0.</p> <p>Present Position Read completed (Done) turns ON while the enable present position is read and output.</p> <p>The Error Flag (Error) will be turned ON and the Error Code (Error code) will be output if an error occurs for this FB. Strictly speaking, they are respectively turned ON or output only when Unit No. (UnitNo) or Axis No. (Axis) is set out of range.</p> <p>Turning OFF Output enabled (Enable) will reset the status.</p>	
<b>FB precautions</b>		
<b>EN input condition</b>	<ul style="list-style-type: none"> <li>• Connect the EN input to the Always On Flag (P_On).</li> <li>• If a different type of bit is connected to EN, the FB outputs will be maintained when the connected bit is turned OFF.</li> </ul>	
<b>Restriction Other</b>		

<p><b>Application example</b></p>	<p>When the Bit A turns ON, the present position of the Servomotor (X-axis) connected to the Motion Control Unit of the Unit No. 0 is read and stored in D0.</p> <p>Unit No.: 0</p> <p>CPU      MCx</p> <p>Servomotor X-axis</p> <p>Always ON( P_On)</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: right;">Unit No. &amp;0</td> <td style="text-align: left;">UnitNo (INT)</td> <td style="text-align: left;">ENO (BOOL)</td> <td style="text-align: left;"><i>Present Position Read completed</i></td> </tr> <tr> <td style="text-align: right;">Axis No. &amp;1</td> <td style="text-align: left;">Axis (INT)</td> <td style="text-align: left;">Done (BOOL)</td> <td style="text-align: left;"><i>Bit B</i></td> </tr> <tr> <td style="text-align: right;">Output enabled Bit A</td> <td style="text-align: left;">Enable (BOOL)</td> <td style="text-align: left;">Error (WORD)</td> <td style="text-align: left;"><i>Error flag</i></td> </tr> <tr> <td style="text-align: right;">Model selection &amp;2</td> <td style="text-align: left;">Select (INT)</td> <td style="text-align: left;">ErrorID (REAL)</td> <td style="text-align: left;"><i>Bit C</i></td> </tr> <tr> <td></td> <td style="text-align: left;">Position (REAL)</td> <td style="text-align: left;">Position D0</td> <td style="text-align: left;"><i>Error code</i></td> </tr> </table>	Unit No. &0	UnitNo (INT)	ENO (BOOL)	<i>Present Position Read completed</i>	Axis No. &1	Axis (INT)	Done (BOOL)	<i>Bit B</i>	Output enabled Bit A	Enable (BOOL)	Error (WORD)	<i>Error flag</i>	Model selection &2	Select (INT)	ErrorID (REAL)	<i>Bit C</i>		Position (REAL)	Position D0	<i>Error code</i>
Unit No. &0	UnitNo (INT)	ENO (BOOL)	<i>Present Position Read completed</i>																		
Axis No. &1	Axis (INT)	Done (BOOL)	<i>Bit B</i>																		
Output enabled Bit A	Enable (BOOL)	Error (WORD)	<i>Error flag</i>																		
Model selection &2	Select (INT)	ErrorID (REAL)	<i>Bit C</i>																		
	Position (REAL)	Position D0	<i>Error code</i>																		
<p><b>Related manuals</b></p>	<p>CS1W-MC221(-V1)/421(-V1) Motion Control Units Operation Manual (W359)</p>																				

■ Variable Tables

**Input Variables**

Name	Variable name	Data type	Default	Range	Description
EN	EN	BOOL			1 (ON): Starts FB 0 (OFF): Does not start FB
Unit No.	UnitNo	INT	&0	&0 to &93 &0 to &91	Depends on the model of Motion Control Units. &0 to &95 (MC221) &0 to &91 (MC421)
Axis No.	Axis	INT	&1	&1 to &4	&1: X-axis &2: Y-axis &3: Z-axis &4: U-axis
Output enabled	Enable	BOOL	0(OFF)		1 (ON): Output enabled 0 (OFF): Output reset
Model selection	Select	INT	&4	&2, &4	&2: 2-axis Unit (MC221) &4: 4-axis Unit (MC421)

**Output Variables**

Name	Variable name	Data type	Range	Description
ENO	ENO	BOOL		1 (ON): FB operating normally 0 (OFF): FB not operating normally/FB ended with error
Present Position Read completed	Done	BOOL		This turns ON when Axis Error Read is completed normally.
Error flag	Error	BOOL		This turns ON when Axis Error Read is ended with an error.
Error code	ErrorID	WORD		The error code of the error occurred in the FB will be output. For details of the errors, refer to the manual listed in the Related manuals above. When Unit No. or Axis No. is out of the range or when a bit to be used for this FB is already ON, #0000 will be output.
Present position	Position	REAL		Feedback present position of each axis controlled by the Motion Control Unit is read and output.

**Version History**

Version	Date	Contents
1.00	2005.4	Original production

**Note**

This manual is a reference that explains the function block functions.

It does not explain the operational limitations of Units, components, or combinations of Units and components. Always read and understand the Operation Manuals for the system's Units and other components before using them.