

NC2x630	Override Setting _NC2x630_SetOverride
----------------	--

Basic function	Sets the override value.						
Symbol							
File name	Lib\FBL\omronlib\PositionController\NC2x\ _NC2x630_SetOverride10.cxf						
Applicable models	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Position Control Units</td> <td>CJ1W-NC214/234/414/434</td> </tr> <tr> <td>CPU Unit</td> <td>CJ1*-CPU**H Version 3.0 or later CJ1M-CPU** Version 3.0 or later CP1H CJ2H-CPU**(-EIP)</td> </tr> <tr> <td>CX-Programmer</td> <td>Version 5.0 or later</td> </tr> </table>	Position Control Units	CJ1W-NC214/234/414/434	CPU Unit	CJ1*-CPU**H Version 3.0 or later CJ1M-CPU** Version 3.0 or later CP1H CJ2H-CPU**(-EIP)	CX-Programmer	Version 5.0 or later
Position Control Units	CJ1W-NC214/234/414/434						
CPU Unit	CJ1*-CPU**H Version 3.0 or later CJ1M-CPU** Version 3.0 or later CP1H CJ2H-CPU**(-EIP)						
CX-Programmer	Version 5.0 or later						
Languages in function block definitions	Ladder programming						
Conditions for usage	None.						
機能説明	<ul style="list-style-type: none"> • For the axis specified in "Unit No. (UnitNo)" and "Axis No. (Axis)", the target speed will be changed by the input value of "Override ratio (VelFactor)" when "Override enable (Enable)" turns ON. • "Setting completed (Enabled)" will turn ON when the override command acceptance is completed. • "Error (Error)" will be turned ON "Error code (ErrorID)" will be output if an error occurs for the FB. This will not occur for error in other FBs or other instances of the FB. • These statuses (Enabled/Error/ErrorID) will be reset when "Override enable (Enable)" turns OFF. 						
Kind of FB definition	<p>Always execution type.</p> <p>Connect the EN input to the Always ON Flag (P_On).</p> <p>The same instance cannot be used in two or more places.</p>						
EN input condition	<ul style="list-style-type: none"> • Connect the EN input to the Always ON Flag (P_On). • If another bit is connected to EN, the FB outputs will be held when the connected bit turns OFF. 						
Restrictions Other	<ul style="list-style-type: none"> • This FB does not recognize the existence of the axis specified in "Unit No. (UnitNo)" and "Axis (Axis)". If these input variables have not been set correctly, the FB may not work normally. • While "Override enable (Enable)" turns ON even after the setting has been completed, the value of "Override ratio (VelFactor)" can be used for the operation. If multiple instances are in operation, the command value of the instance located the lowest will be used for the operation. • This FB uses bits of the Position Control Unit. Therefore, do not turn these bits ON or OFF. For the same reason, do not use these bits for coil outputs (OUT commands). <p>Refer to the "■Used bits list" for the bits used by this FB.</p>						

Application example

Turning ON bit A will enable the override of the axis (Axis 1) connected to the Position Control Unit of unit number 0.

Related manuals

CJ-series Position Control Unit Operation Manual (W477)
9-3 Override

Variable Tables
Input Variables

Name	Variable name	Data type	Default	Range	Description
EN	EN	BOOL			1(ON): FB started 0(OFF): FB not started
Unit No.	UnitNo	INT	&0	&0 to &94	Specify the unit number.
Axis	Axis	INT	&1	&1 to &4	Specify the axisnumber.
Override enable	Enable	BOOL	0(OFF)		↑ : Override enabled ↓ : Override disabled
Override ratio	VelFactor	UINT	&1	&1 to &50000	Specify the override ratio. Unit: 0.01% If the value is changed when "Override enable (Enable)" is ON, the actual override value will change.

Output Variables

Name	Variable name	Data type	Range	Description
ENO	ENO	BOOL		1(ON): FB operating normally 0(OFF): FB not started / FB ended with error
Setting completed	Enabled	BOOL		Turns ON when the override setting is completed.
Error flag	Error	BOOL		Turns ON when an error has occurred in the FB. Refer to "Error code (ErrorID)" for details.
Error code	ErrorID	WORD		Returns the error code when an error occurred in the FB. Refer to "■Error code list" for details.

■Error code list

Error name	Error code	Probable cause	Clearing method
Input variable out of range	#0001	The value of input variable of this FB is out of valid range.	Set the value of input variable within the specified range.
Operating memory area allocation out of range	#0002	The allocation of Axis Operating Memory Area of Common Parameter is out of allowable setting range.	Correct the allocation of Axis Operating Memory Area of Common Parameter so that it falls within the allowable setting range of data.

■Used bits list

Memory area	Name	Data type	Address	Note
Manual Operation Command Memory area	Override enable	BOOL	A+00.05	
	Override	UINT	A+01	

■Version History

Version	Date	Contents
1.00	2009.06.	Original production.

■Note

This document explains the function of the function block.
It does not provide information of restrictions on the use of Units and Components or combination of them. For actual applications, make sure to read the operation manuals of the applicable products.