

<b>NCF 080</b>	<b>Reset Axis Error _NCF080_Reset</b>
--------------------	---------------------------------------

<b>Basic function</b>	Resets an axis error.																																								
<b>Symbol</b>																																									
<b>File name</b>	Lib\FBL\omronlib\PositionController\NCF\_NCF080_Reset11.cxf																																								
<b>Applicable models</b>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Position Unit</td> <td>CJ1W-NCF71, CS1W-NCF71</td> </tr> <tr> <td>CPU Unit</td> <td>CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H</td> </tr> <tr> <td>CX-Programmer</td> <td>Version 5.0 or later</td> </tr> </table>	Position Unit	CJ1W-NCF71, CS1W-NCF71	CPU Unit	CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H	CX-Programmer	Version 5.0 or later																																		
Position Unit	CJ1W-NCF71, CS1W-NCF71																																								
CPU Unit	CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H																																								
CX-Programmer	Version 5.0 or later																																								
<b>Languages in function block definitions</b>	Ladder programming																																								
<b>Conditions for usage</b>	<p>The following conditions for usage should be the Position Control Unit version 1.2 or earlier. (It will not be required in the Position Control Unit version 1.3 or later)</p> <p>■CX-Programmer Setting</p> <p>The function blocks related to the Position Control Units will not operate if the area H512 or higher (default setting) is specified as the Non Retain Area through the Function block memory allocation. Make sure to change the memory area to unused area (DM or EM, for example) from the CX-Programmer. To change this value, click <b>PLC/Function Block Memory/Function Block Memory Allocation</b> from the Menu Bar.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <caption>Function Block Memory Allocation [NewPLC1]</caption> <thead> <tr> <th>FB Instance Area</th> <th>Start Address</th> <th>End Address</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>No Retain</td> <td>H512</td> <td>H1407</td> <td>896</td> </tr> <tr> <td>Retain</td> <td>H1408</td> <td>H1535</td> <td>128</td> </tr> <tr> <td>Timers</td> <td>T3072</td> <td>T4095</td> <td>1024</td> </tr> <tr> <td>Counters</td> <td>C3072</td> <td>C4095</td> <td>1024</td> </tr> </tbody> </table> </div> <p style="margin-left: 20px;">Specify unused area. The required size varies depending on the used FB and the number of FBs. If an area being used in the ladder program is specified or sufficient free space cannot be found, the CX-Programmer will display a compile error.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <caption>Function Block Memory Allocation [NewPLC1]</caption> <thead> <tr> <th>FB Instance Area</th> <th>Start Address</th> <th>End Address</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>No Retain</td> <td>D32020</td> <td>D32767</td> <td>748</td> </tr> <tr> <td>Retain</td> <td>H1408</td> <td>H1535</td> <td>128</td> </tr> <tr> <td>Timers</td> <td>T3072</td> <td>T4095</td> <td>1024</td> </tr> <tr> <td>Counters</td> <td>C3072</td> <td>C4095</td> <td>1024</td> </tr> </tbody> </table> </div> <p style="margin-left: 20px;">For example, to use the memory area from D32020 to D32767 (748 words), specify the addresses as shown in the left.</p>	FB Instance Area	Start Address	End Address	Size	No Retain	H512	H1407	896	Retain	H1408	H1535	128	Timers	T3072	T4095	1024	Counters	C3072	C4095	1024	FB Instance Area	Start Address	End Address	Size	No Retain	D32020	D32767	748	Retain	H1408	H1535	128	Timers	T3072	T4095	1024	Counters	C3072	C4095	1024
FB Instance Area	Start Address	End Address	Size																																						
No Retain	H512	H1407	896																																						
Retain	H1408	H1535	128																																						
Timers	T3072	T4095	1024																																						
Counters	C3072	C4095	1024																																						
FB Instance Area	Start Address	End Address	Size																																						
No Retain	D32020	D32767	748																																						
Retain	H1408	H1535	128																																						
Timers	T3072	T4095	1024																																						
Counters	C3072	C4095	1024																																						
<b>Function description</b>	<p>When the Start (Execute) turns ON, the Reset operation for the axis of the specified Unit No. (UnitNo) and Axis No. (Axis) is started.</p> <p>The Reset completed flag (Done) will turn ON when resetting the error has been completed and commands can be accepted.</p> <p>The Error flag (Error) will be turned ON and the Error code (ErrorID) will be output if an error occurs for the FB. This will not occur for error in other FBs or other instances of the FB.</p> <p>These statuses (Done/CommandAborted/Error/ErrorID) will be reset when the Start (Execute) turns OFF. If the Start (Execute) turns OFF before the Reset operation has been completed, the status will be set for at least one cycle when supporting conditions have occurred.</p>																																								

	<p>Note: The Reset of Position Control Units is used in this FB. Refer to the manual in Related manuals for details.</p>																				
<p><b>Kind of FB definition</b></p>	<p>Always execution type. Connect the EN input to the Always ON Flag (P_On). The same instance cannot be used in two or more places.</p>																				
<p><b>EN input condition</b></p>	<p>•Connect the EN input to the Always ON Flag (P_On). If another bit is connected to EN, the FB outputs will be held when the connected bit turns OFF.</p>																				
<p><b>Restrictions Other</b></p>	<ul style="list-style-type: none"> <li>•Execute this FB when the Busy Flag (Axis Busy Flag) in the Axis Operating Input Memory Areas is OFF. If this FB is executed when the Axis Busy Flag is ON, this FB will be executed right after the Axis Busy Flag turns OFF.</li> <li>•This FB uses Unit Error Reset, Write Data, Read Data and Save Data Bits of the Position Control Unit (see Note). Therefore, do not turn these bits ON or OFF between the rising edge of EN to the rising edge of ENO. For the same reason, do not use these bits for coil outputs (OUT commands).</li> <li>•The output variable of FB may not change even if EN is turned ON. In that case, check if any of Unit Error Reset, Write Data, Read Data and Save Data Bit is left ON.</li> <li>•This FB uses the Error Reset Bit in the Axis Operating Output Memory Areas. Therefore, do not turn these bits ON or OFF until the operation is completed. For the same reason, do not use these bits for coil outputs (OUT commands).</li> </ul> <p>Note: For calculation of bit addresses, these bits are referenced in this FB in the first execution of each instance, and when changing "Unit No. (UnitNo)", "Axis No. (Axis)" of the input variable and set "Start (Execute)".</p>																				
<p><b>Application example</b></p>	<p>Turning the Start Trigger ON from OFF will reset an axis error occurred in the Servomotor (axis1) connected to the Position Control Unit with a unit number 0.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="4">Sample _NCF080_Reset</th> </tr> </thead> <tbody> <tr> <td>(BOOL)</td> <td>EN</td> <td>(BOOL)</td> <td>ENO</td> </tr> <tr> <td>(INT)</td> <td>Unit No. &amp;0</td> <td>(BOOL)</td> <td>Reset completed flag Bit B</td> </tr> <tr> <td>(INT)</td> <td>Axis No. &amp;1</td> <td>(BOOL)</td> <td>Error flag Bit C</td> </tr> <tr> <td>(BOOL)</td> <td>Start Bit A</td> <td>(WORD)</td> <td>Error code ErrorID D0</td> </tr> </tbody> </table>	Sample _NCF080_Reset				(BOOL)	EN	(BOOL)	ENO	(INT)	Unit No. &0	(BOOL)	Reset completed flag Bit B	(INT)	Axis No. &1	(BOOL)	Error flag Bit C	(BOOL)	Start Bit A	(WORD)	Error code ErrorID D0
Sample _NCF080_Reset																					
(BOOL)	EN	(BOOL)	ENO																		
(INT)	Unit No. &0	(BOOL)	Reset completed flag Bit B																		
(INT)	Axis No. &1	(BOOL)	Error flag Bit C																		
(BOOL)	Start Bit A	(WORD)	Error code ErrorID D0																		
<p><b>Related manuals</b></p>	<p>CJ1W-NCF71 Position Control Unit Operation Manual (W426) 12-4 Error Codes 12-6 Error Reset</p>																				

## ■ Variable Tables

### Input Variables

Name	Variable name	Data type	Default	Range	Description
EN	EN	BOOL			1 (ON): FB started 0 (OFF): FB not started.
Unit No.	UnitNo	INT	&0	&0 to &15	Specify the unit number.
Axis No.	Axis	INT	&1	&1 to &16	Specify the axis number.
Start	Execute	BOOL	0(OFF)		↕ : Starts the reset.

### Output Variables

Name	Variable name	Data type	Range	Description
ENO	ENO	BOOL		1 (ON): FB operating normally 0 (OFF): FB not operating normally <ul style="list-style-type: none"> <li>•FB not started</li> <li>•Input variable out of the range</li> <li>•FB ended with error</li> <li>•Common Parameters could not be read</li> </ul>
Reset completed flag	Done	BOOL		Turns ON when the error reset operation has been completed.
Error flag	Error	BOOL		Turns ON when an error has occurred in the FB.
Error code	ErrorID	WORD		Returns the error code when an error has occurred in the FB. Refer to the <i>Related Manuals</i> for details on errors. A code of #0000 will be returned if any of the following conditions is satisfied. <ul style="list-style-type: none"> <li>•Input variable is out of range.</li> <li>•The common parameters of the Position Control Units are out of range.</li> <li>•Not established communications with a specified axis.</li> <li>•The Error Reset Bit is changed by the other FB during Error Reset in operation.</li> </ul>

### ■Version History

Version	Date	Contents
1.00	2004.06.	Original production
1.10	2005.01.	Limitation about the setting timing with " Unit No. " and " Axis No. " was removed.

### ■ The detailed contents of the upgrading

Version	Detailed Contents
1.10	In version 1.00, " Unit No. " and " Axis No. " must be set when EN was ON and " Start (Execute) " was OFF. This means not sometimes working normally when " Unit No. " and " Axis No. " are changed simultaneously with ON of " Start (Execute) ". In version 1.10, this limitation was removed.

### ■Note

This document explains the function of the function block.

It does not provide information of restrictions on the use of Units and Components or combination of them. For actual applications, make sure to read the operation manuals of the applicable products.