



NCF 203A	Read Axis Error _NCF203A_ReadAxisError
-----------------	---

Basic function	Reads error information of an axis. (Busy attachment)																																								
Symbol																																									
File name	Lib\FBL\omronlib\PositionController\NCF_NCF203A_ReadAxisError11.cfx																																								
Applicable models	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Position Unit</td> <td>CJ1W-NCF71, CS1W-NCF71</td> </tr> <tr> <td>CPU Unit</td> <td>CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H</td> </tr> <tr> <td>CX-Programmer</td> <td>Version 5.0 or later</td> </tr> </table>	Position Unit	CJ1W-NCF71, CS1W-NCF71	CPU Unit	CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H	CX-Programmer	Version 5.0 or later																																		
Position Unit	CJ1W-NCF71, CS1W-NCF71																																								
CPU Unit	CS1*-CPU**H Unit Version 3.0 or later CJ1*-CPU**H Unit Version 3.0 or later CJ1M-CPU** Unit Version 3.0 or later CP1H																																								
CX-Programmer	Version 5.0 or later																																								
Languages in function block definitions	Ladder programming																																								
Conditions for usage	<p>The following conditions for usage should be the Position Control Unit version 1.2 or earlier. (It will not be required in the Position Control Unit version 1.3 or later)</p> <p>■CX-Programmer Setting</p> <p>The function blocks related to the Position Control Units will not operate if the area H512 or higher (default setting) is specified as the Non Retain Area through the Function block memory allocation. Make sure to change the memory area to unused area (DM or EM, for example) from the CX-Programmer. To change this value, click PLC/Function Block Memory/Function Block Memory Allocation from the Menu Bar.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <caption>Function Block Memory Allocation [NewPLC1]</caption> <thead> <tr> <th>FB Instance Area</th> <th>Start Address</th> <th>End Address</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>No Retain</td> <td>H512</td> <td>H1407</td> <td>896</td> </tr> <tr> <td>Retain</td> <td>H1408</td> <td>H1535</td> <td>128</td> </tr> <tr> <td>Timers</td> <td>T3072</td> <td>T4095</td> <td>1024</td> </tr> <tr> <td>Counters</td> <td>C3072</td> <td>C4095</td> <td>1024</td> </tr> </tbody> </table> </div> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <caption>Function Block Memory Allocation [NewPLC1]</caption> <thead> <tr> <th>FB Instance Area</th> <th>Start Address</th> <th>End Address</th> <th>Size</th> </tr> </thead> <tbody> <tr> <td>No Retain</td> <td>D32020</td> <td>D32767</td> <td>748</td> </tr> <tr> <td>Retain</td> <td>H1408</td> <td>H1535</td> <td>128</td> </tr> <tr> <td>Timers</td> <td>T3072</td> <td>T4095</td> <td>1024</td> </tr> <tr> <td>Counters</td> <td>C3072</td> <td>C4095</td> <td>1024</td> </tr> </tbody> </table> </div> <p style="margin-left: 20px;">Specify unused area. The required size varies depending on the used FB and the number of FBs. If an area being used in the ladder program is specified or sufficient free space cannot be found, the CX-Programmer will display a compile error.</p> <p style="margin-left: 20px;">For example, to use the memory area from D32020 to D32767 (748 words), specify the addresses as shown in the left.</p>	FB Instance Area	Start Address	End Address	Size	No Retain	H512	H1407	896	Retain	H1408	H1535	128	Timers	T3072	T4095	1024	Counters	C3072	C4095	1024	FB Instance Area	Start Address	End Address	Size	No Retain	D32020	D32767	748	Retain	H1408	H1535	128	Timers	T3072	T4095	1024	Counters	C3072	C4095	1024
FB Instance Area	Start Address	End Address	Size																																						
No Retain	H512	H1407	896																																						
Retain	H1408	H1535	128																																						
Timers	T3072	T4095	1024																																						
Counters	C3072	C4095	1024																																						
FB Instance Area	Start Address	End Address	Size																																						
No Retain	D32020	D32767	748																																						
Retain	H1408	H1535	128																																						
Timers	T3072	T4095	1024																																						
Counters	C3072	C4095	1024																																						

<p>Function description</p>	<p>The Busy Output is added to the _NCF203_ReadAxisError in this FB.</p> <p>Axis error information for the axis of the specified Unit No. (UnitNo) and Axis No. (Axis) is read when the Read Axis Error (Enable) is turned ON.</p> <p>The Read Completed (Done) turns ON when there is no error on the Unit.</p> <p>The Busy flag (Busy) will be set when the Read Axis Error (Enable) is turned ON.</p> <p>The Busy flag (Busy) will be reset when the Read Completed (Done) or Error flag (Error) is turned ON.</p> <p>If the error is occurred when the input variables is out of the range etc., the Busy flag (Busy) will be set for at least one cycle.</p> <p>The Error fag (Error) and the Error code (ErrorID) will show the status of errors for the Position Control Unit axis. The Error flag (Error) will also be turned ON when the unit number or axis number is not in range.</p> <p>These statuses (Done/Error/ErrorID) will be reset when the Read Axis Error (Enable) turns OFF.</p> 
<p>Kind of FB definition</p>	<p>Always execution type.</p> <p>Connect the EN input to the Always ON Flag (P_On).</p> <p>The same instance cannot be used in two or more places.</p>
<p>EN input condition</p>	<p>• Connect the EN input to the Always ON Flag (P_On).</p> <p>If another bit is connected to EN, the FB outputs will be held when the connected bit turns OFF.</p>
<p>Restrictions Other</p>	<ul style="list-style-type: none"> • The Error Flag (Error) and Error Code (ErrorID) for this FB reflect the status of the Operating Input Memory Area in the Position Control Unit without alteration. • This FB uses Unit Error Reset, Write Data, Read Data and Save Data Bits of the Position Control Unit (see Note). Therefore, do not turn these bits ON or OFF between the period from the rising edge of EN to the rising edge of ENO. For the same reason, do not use these bits for coil outputs (OUT commands). • The output variable of FB may not change even if EN is turned ON. In that case, check if any of Unit Error Reset, Write Data, Read Data and Save Data Bit is left ON. <p>Note: For calculation of bit addresses, these bits are referenced in this FB in the first execution of each instance, and when changing "Unit No. (UnitNo)", "Axis No. (Axis)" of the input variable and set "Output Enable Bit (Enable)".</p>
<p>Application example</p>	<p>When turning the Bit A ON from OFF, the axis error information of axis 1 of the Servomotor connected to the Position Control Unit with unit number 0 is read and stored in D0.</p> 
<p>Related manuals</p>	<p>Position Control Units OPERATION MANUAL (W426-E1) 12-4 Error Codes</p>

■ Variable Tables

Input Variables

Name	Variable name	Data type	Default	Range	Description
EN	EN	BOOL			1 (ON): FB started 0 (OFF): FB not started
Unit No.	UnitNo	INT	&0	&0 to &15	Specify the unit number.
Axis No.	Axis	INT	&1	&1 to &16	Specify the axis number.
Read Axis Error	Enable	BOOL	0(OFF)		↑ : Starts reading error

Output Variables

Name	Variable name	Data type	Range	Description
ENO	ENO	BOOL		1 (ON): FB operating normally 0 (OFF): FB not operating normally <ul style="list-style-type: none"> •FB not started •Input variable out of the range •FB ended with error •Common Parameters could not be read
Read Completed	Done	BOOL		1 (ON) indicates that there is no error on the specified axis.
Busy flag	Busy	BOOL		1 (ON) indicates that the FB is in progress.
Error flag	Error	BOOL		Turns ON when an error has occurred in the specified axis.
Error code	ErrorID	WORD		Returns the error code when an error has occurred in the FB. Refer to the <i>Related Manuals</i> for details on errors. A code of #0000 will be returned if any of the following conditions is satisfied. <ul style="list-style-type: none"> •Input variable is out of range. •The common parameters of the Position Control Units are out of range. •Not established communications with a specified axis.

■ Version History

Version	Date	Contents
1.13	2006.01.	Original production

■ Note

This document explains the function of the function block.

It does not provide information of restrictions on the use of Units and Components or combination of them. For actual applications, make sure to read the operation manuals of the applicable products.