

CARD 410	Write IOM File: _CARD410_WriteIOM
-----------------	--

Basic function	Saves I/O data to the Memory Card as a binary data file (extension .IOM).																
Symbol	<div style="display: flex; align-items: center;"> <div style="flex: 1;"> </div> <div style="flex: 2; border: 1px solid black; padding: 5px; margin-left: 10px;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; border-right: 1px solid black; padding: 2px;">_CARD410_WriteIOM</td> <td style="width: 50%; padding: 2px;"></td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">EN (BOOL)</td> <td style="padding: 2px;">(BOOL) ENO</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">DirName (LWORD)</td> <td style="padding: 2px;">FB_BUSY (BOOL)</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">FileName (LWORD)</td> <td style="padding: 2px;">FB_OK (BOOL)</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">AreaID (WORD)</td> <td style="padding: 2px;">FB_NG (BOOL)</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">AreaNo (INT)</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">Num (UINT)</td> <td style="padding: 2px;"></td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">OverWrite (UINT)</td> <td style="padding: 2px;"></td> </tr> </table> </div> </div>	_CARD410_WriteIOM		EN (BOOL)	(BOOL) ENO	DirName (LWORD)	FB_BUSY (BOOL)	FileName (LWORD)	FB_OK (BOOL)	AreaID (WORD)	FB_NG (BOOL)	AreaNo (INT)		Num (UINT)		OverWrite (UINT)	
_CARD410_WriteIOM																	
EN (BOOL)	(BOOL) ENO																
DirName (LWORD)	FB_BUSY (BOOL)																
FileName (LWORD)	FB_OK (BOOL)																
AreaID (WORD)	FB_NG (BOOL)																
AreaNo (INT)																	
Num (UINT)																	
OverWrite (UINT)																	
File name	Lib\FBL\omronlib\PLC\Card\ _CARD410_WriteIOM10.cxf																
Applicable models	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%; border-right: 1px solid black; padding: 2px;">CPU Unit</td> <td style="padding: 2px;">CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 2px;">CX-Programmer</td> <td style="padding: 2px;">Version 5.0 or higher</td> </tr> </table>	CPU Unit	CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher	CX-Programmer	Version 5.0 or higher												
CPU Unit	CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher																
CX-Programmer	Version 5.0 or higher																
Conditions for usage	<p>Shared Resources</p> <ul style="list-style-type: none"> • Memory Card <p>Memory Card Status</p> <ul style="list-style-type: none"> • The Memory Card must be recognized by the CPU Unit. The Memory Card Recognized Flag (A343.15) will be ON when CPU Unit has recognized the Memory Card. 																
Function description	<p>When the Start Trigger turns ON, the function saves the specified I/O memory data as an IOM file (.IOM extension) in the Memory Card's root directory. Up to 65,535 words of data can be saved. The "Write mode" can be set to write additional data or overwrite a file. When a file already exists with the same name, that file will be overwritten.</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="flex: 1;"> <p>Start word for data storage</p> <p>Number of words to store</p> </div> <div style="flex: 2; border: 1px solid gray; padding: 5px; margin: 0 10px;"> <p style="text-align: center; border-bottom: 1px solid gray;">CPU Unit</p> <div style="background-color: #cccccc; width: 100%; height: 20px; margin: 5px 0;"></div> </div> <div style="flex: 1; text-align: center;"> <p>Memory Card</p> <div style="border: 1px solid gray; padding: 5px; width: 60px; margin: 0 auto;">I/O memory file</div> </div> </div>																
FB precautions	<ul style="list-style-type: none"> • If the Memory Card is already being accessed when the FB is started, the operation will be performed after the completion of the access. • The FB is processed over multiple cycles. The FB_BUSY output variable can be used to check whether the FB is being processed. • <i>FB_OK</i> or <i>FB_NG</i> will be turned ON for one cycle only after processing is completed. Use these flags to detect the end of FB processing. <p>■ Timing Chart</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="flex: 1; padding-right: 10px;"> <p>Start Trigger</p> <p>FB Busy Flag (FB_BUSY)</p> <p>FB Normal End (FB_OK) or FB Error End (FB_NG)</p> </div> <div style="flex: 2;"> </div> </div> <p style="text-align: right; margin-top: 10px;">When the Normal End Flag goes ON, the file has been created.</p> <ul style="list-style-type: none"> • This FB writes data to the Memory Card over a number of cycles. Consequently, the data will not be simultaneous. To preserve data simultaneity, transfer the desired data to a separate data area and use this FB to create a file from the data in that data area. Refer to the <i>Application example</i> below for a specific example. 																
EN input condition	Connect EN to an OR between an upwardly differentiated condition for the start trigger and the FB_BUSY output from the FB.																
Restrictions Input variables	<ul style="list-style-type: none"> • Always use an upwardly differentiated condition for EN. • If the input variables are out of range, the ENO Flag will turn OFF and the FB will not be processed. 																
Output variables	<ul style="list-style-type: none"> • This FB requires multiple cycles to process. Always connect an OR including the FB_BUSY output variable to the EN input variable to ensure that the FB is processed to completion (see <i>Symbol</i>). • Do not turn the FB_BUSY output variable ON or OFF outside the FB. 																

Other

- If the Memory Card is missing or cannot be detected, the FB_NG Flag will be turned ON.
- Never turn OFF the Power Supply when the CPU Unit's BUSY indicator (Accessing Memory Card indicator) is lit.
Refer to the Related Manuals for other Memory Card precautions.

Application example

In this example, the 100 words from D1000 to D1099 are refreshed every cycle by a data link.
The following program section saves the 100 words from D1000 to D1099 while preserving simultaneity.

- When bit A goes ON, the 100 words from D1000 to D1099 are copied to W400 to W499.
- A file called *ABCDE.IOM* is created in the Memory Card's root directory. The 100 words of data (read from D1000 to D1099 when bit A went ON) are saved to that file.
The simultaneity of this data is preserved.

- Start Trigger Bit V is connected to the EN input of the _CARD210_ReadIOM function block. Bit W is connected to ENO. Bit X is connected to FB_BUSY. Bit Y is connected to FB_OK and FB_NG. The function block has inputs for Directory name (#00), File name (#4142434445000000), Area ID for read data storage (P_DM), Area No. for read data storage (&2000), Read data size (D0), and Num.

Related manuals

Precautions when Using a Memory Card

There are several precautions that must be observed when using Memory Cards. This manual provides just an overview of the precautions. For details, refer to 5-1 File Memory in the *CS/CJ Series Programmable Controllers Programming Manual (W394-E1)*.

- 1) Format**
The Memory Card is already formatted when it is shipped, so it is not necessary to format a newly purchased Card.
- 2) Number of Files allowed in Root Directory**
There is a limit to the number of files that can be stored in the root directory of the Memory Card. The maximum number of files depends on the Memory Card model and format, but it ranges between 128 and 512 files.
- 3) Maximum Number of Overwrites**
A limit of 100,000 write operations has been set for warranty purposes. For example, if the Memory Card is written to every 10 minutes, over 100,000 write operations will be performed within 2 years.
- 4) Turning the Power OFF**
Never turn OFF the Power Supply when the CPU Unit's BUSY indicator (Accessing Memory Card indicator) is lit.

Reference for File Data Format

For details on file formats, refer to 5-1-3 Files in the *CS/CJ Series Programmable Controllers Programming Manual (W394-E1)*.

Related FBs

Use the following functions when setting the present date or time as the directory name or file name.

- FB Get Date in ASCII (_CPU020_MakeAsciiDate)
- FB Get Time in ASCII (_CPU021_MakeAsciiTime)

Variable Tables

Input Variables

Name	Variable name	Data type	Default	Range	Description								
EN	EN	BOOL			1 (ON): FB started 0 (OFF): FB not started.								
Directory name	DirName	LWORD		At right.	<p>Specifying the root directory: Set the directory to #00.</p> <p>Specifying a subdirectory: Specify the directory name (always 8 characters) in ASCII with the character codes at the beginning. If fewer than 8 characters are required, pad the extra characters with zeroes (#00). For example, to set the name "ABCD," input #4142434400000000.</p> <p>When indirectly specifying ASCII data in data area words, input the data as shown below.</p> <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>n+3</td> <td>#3132</td> </tr> <tr> <td>n+2</td> <td>#33334</td> </tr> <tr> <td>n+1</td> <td>#3536</td> </tr> <tr> <td>n</td> <td>#3738</td> </tr> </table> <p style="font-size: small; margin-left: 20px;">In this case, the directory name is "12345678".</p>	n+3	#3132	n+2	#33334	n+1	#3536	n	#3738
n+3	#3132												
n+2	#33334												
n+1	#3536												
n	#3738												
File name	FileName	LWORD		At right.	<p>Specify the file name (always 8 characters) in ASCII with the character codes at the beginning. If fewer than 8 characters are required, pad the extra characters with zeroes (#00).</p> <p>For example, to set the name "123.IOM," input #3132330000000000.</p> <p>When indirectly specifying ASCII data in data area words, input the data as shown below.</p> <table border="1" style="display: inline-table; vertical-align: middle;"> <tr> <td>n+3</td> <td>#3132</td> </tr> <tr> <td>n+2</td> <td>#3334</td> </tr> <tr> <td>n+1</td> <td>#3536</td> </tr> <tr> <td>n</td> <td>#3738</td> </tr> </table> <p style="font-size: small; margin-left: 20px;">In this case, the file name is "12345678.IOM".</p>	n+3	#3132	n+2	#3334	n+1	#3536	n	#3738
n+3	#3132												
n+2	#3334												
n+1	#3536												
n	#3738												
Area ID for write data storage	AreaID	WORD	#0082	At right.	P_CIO (#00B0): CIO Area P_WR (#00B1): Work Area P_HR (#00B2): Holding Area P_DM (#0082): DM Area P_EM0 (#0050) to P_EM5 (#005C): EM Area bank 0 to C								
Area No. for write data	AreaNo	INT	&0										
Write data size	Num	UINT	&0										
Write mode	OverWrite	UINT	&0	&0 to &1	Specify this write mode if the file already exists. &0: Add data &1: Overwrite When creating a new file, specify "&0: Add data".								

Output Variables

Name	Variable name	Data type	Range	Description
ENO (May be omitted.)	ENO	BOOL		1 (ON): FB processed normally. 0 (OFF): FB not processed or ended in an error.
FB Busy Flag	FB_BUSY	BOOL		Automatically turns OFF when processing is completed.
FB Normal end	FB_OK	BOOL		Turns ON for one cycle when processing ends normally.
FB Error end	FB_NG	BOOL		Turns ON for one cycle when processing ends in an error.

Reference


ASCII Table

Text	ASCII	Text	ASCII	Text	ASCII	Text	ASCII	Text	ASCII	Text	ASCII
0	#30	8	#38			H	#48	P	#50	X	#58
1	#31	9	#39	A	#41	I	#49	Q	#51	Y	#59
2	#32			B	#42	J	#4A	R	#52	Z	#5A
3	#33			C	#43	K	#4B	S	#53		
4	#34			D	#44	L	#4C	T	#54		
5	#35			E	#45	M	#4D	U	#55		
6	#36			F	#46	N	#4E	V	#56		
7	#37			G	#47	O	#4F	W	#57		

Examples:
 Character 0: ASCII #30
 Character A: ASCII #41
 Character X: ASCII #58

Exceeding Data Area Boundaries

The following diagram shows the arrangement of the CPU Unit's I/O memory.
 If the specified number of read words exceeds the specified data area's capacity, another data area will also be overwritten.



Version History

Version	Date	Contents
1.00	2005.2.	Original production

Note

This manual is a reference that explains the function block functions.
 It does not explain the operational limitations of Units, components, or combinations of Units and components. Always read and understand the Operation Manuals for the system's Units and other components before using them.