

ExxDRT 207 **Read Status: _ExxDRT207_ReadStatus**

Basic function	Reads the status of a Digital Type Sensor in the DeviceNet network.																														
Symbol		<div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">_ExxDRT207_ReadStatus</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">(BOOL) EN</td> <td style="width: 50%;">(BOOL) ENO</td> <td></td> </tr> <tr> <td>(INT) MasterUnitNo</td> <td>(BOOL) FB_BUSY</td> <td rowspan="2">FB Busy Flag</td> </tr> <tr> <td>(INT) NodeNo</td> <td>(BOOL) FB_OK</td> </tr> <tr> <td></td> <td>(BOOL) FB_OK</td> <td rowspan="2">FB Normal End</td> </tr> <tr> <td></td> <td>(BOOL) FB_NG</td> </tr> <tr> <td></td> <td>(BOOL) FB_NG</td> <td rowspan="2">FB Error End</td> </tr> <tr> <td></td> <td>(BOOL) SensorComError</td> </tr> <tr> <td></td> <td>(BOOL) Communicating</td> <td rowspan="2">Communications Error with Sensor</td> </tr> <tr> <td></td> <td>(BOOL) MCCCommunicating</td> </tr> <tr> <td></td> <td></td> <td>Communicating with Sensor</td> </tr> <tr> <td></td> <td></td> <td>Communicating with Mobile Console</td> </tr> </table> </div>	(BOOL) EN	(BOOL) ENO		(INT) MasterUnitNo	(BOOL) FB_BUSY	FB Busy Flag	(INT) NodeNo	(BOOL) FB_OK		(BOOL) FB_OK	FB Normal End		(BOOL) FB_NG		(BOOL) FB_NG	FB Error End		(BOOL) SensorComError		(BOOL) Communicating	Communications Error with Sensor		(BOOL) MCCCommunicating			Communicating with Sensor			Communicating with Mobile Console
(BOOL) EN	(BOOL) ENO																														
(INT) MasterUnitNo	(BOOL) FB_BUSY	FB Busy Flag																													
(INT) NodeNo	(BOOL) FB_OK																														
	(BOOL) FB_OK	FB Normal End																													
	(BOOL) FB_NG																														
	(BOOL) FB_NG	FB Error End																													
	(BOOL) SensorComError																														
	(BOOL) Communicating	Communications Error with Sensor																													
	(BOOL) MCCCommunicating																														
		Communicating with Sensor																													
		Communicating with Mobile Console																													
File name	Lib\FBL\omronlib\DigitalTypeSensor\ExxDRT_ExxDRT207_ReadStatus10.cxf																														
Applicable models	Applicable Master Units	CS1W-DRM21(-V1) and CJ1W-DRM21																													
	Applicable Slave Units	E3X-DRT21-S																													
	Applicable Sensor Amplifiers	E3X Series: E3X-DA-S, E3X-MDA, E3X-DATW-S, and E3X-DARM-S E3C Series: E3C-LDA two-output models and E3C-LDA input models E2C Series: E2C-EDA two-output models and E2C-EDA input models																													
	CPU Unit	CS1*-CPU** Unit version 3.0 or higher CJ1*-CPU** Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher CP1H																													
	CX-Programmer	Version 5.0 or higher																													
Conditions for usage	<p>Sensor</p> <ul style="list-style-type: none"> If a Mobile Console is connected when the power is turned ON, the function cannot be used because communications cannot be established with the Sensor. The Sensor must be in RUN mode. The function cannot be used when the Sensor is in another mode, i.e., SET mode. <p>CPU Unit Settings</p> <p>PLC Setup: Shared Settings for Communications Instructions in FBs</p> <ul style="list-style-type: none"> DeviceNet Response Timeout Time (default: 2 s) A Timeout time of 10 s or higher is recommended. Number of retries (default: 0) <p>Shared Resources</p> <ul style="list-style-type: none"> Communications ports (internal logical ports) <p>Other</p> <ul style="list-style-type: none"> Communications must be within one network and cannot cross to another network. 																														
Function description	Reads the communications status (communications error with Sensor, communicating with Sensor, or communicating with Mobile Console) of the Digital Sensor Communications Unit in the DeviceNet network with the specified Master Unit number and Slave node address.																														
FB precautions	<ul style="list-style-type: none"> The FB is processed over multiple cycles. The FB_BUSY output variable can be used to check whether the FB is being processed. FB_OK or FB_NG will be turned ON for one cycle only after processing is completed. Use these flags to detect the end of FB processing. <p>■ Timing Chart</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Start Trigger</td> <td style="width: 10%;">ON OFF</td> <td style="width: 10%;"></td> <td style="width: 60%;"></td> </tr> <tr> <td>FB Busy Flag (FB_BUSY)</td> <td>ON OFF</td> <td></td> <td></td> </tr> <tr> <td>FB Normal End (FB_OK) or FB Error End (FB_NG)</td> <td>ON OFF</td> <td></td> <td></td> </tr> <tr> <td>Communications Error with Sensor Communicating with Sensor Communicating with Mobile Console</td> <td>ON OFF</td> <td></td> <td></td> </tr> </table>		Start Trigger	ON OFF			FB Busy Flag (FB_BUSY)	ON OFF			FB Normal End (FB_OK) or FB Error End (FB_NG)	ON OFF			Communications Error with Sensor Communicating with Sensor Communicating with Mobile Console	ON OFF															
Start Trigger	ON OFF																														
FB Busy Flag (FB_BUSY)	ON OFF																														
FB Normal End (FB_OK) or FB Error End (FB_NG)	ON OFF																														
Communications Error with Sensor Communicating with Sensor Communicating with Mobile Console	ON OFF																														
EN input condition	Connect EN to an OR between an upwardly differentiated condition for the start trigger and the FB_BUSY output from the FB.																														
Restrictions Input variables	<ul style="list-style-type: none"> Always use an upwardly differentiated condition for EN. If the input variables are out of range, the ENO Flag will turn OFF and the FB will not be processed. 																														

<p>Output variables</p>	<ul style="list-style-type: none"> • This FB requires multiple cycles to process. Always connect an OR including the FB_BUSY output variable to the EN input variable to ensure that the FB is processed to completion (see <i>Symbol</i>). • Do not turn the FB_BUSY output variable ON or OFF outside the FB. 																								
<p>Application example</p>	<p>This example shows the detection of a sensor communications error. A Digital Sensor Communication Unit (node 11) is connected to a DeviceNet Unit with Master unit number 10. When bit A is turned from OFF to ON, the function checks the Digital Sensor Communication Unit for sensor communications errors.</p> <p>Master Unit No. 10</p> <p>DRM CPU</p> <p>Slave node address 11</p> <p>E3X DRT E3X No1 E3X No2</p> <p>Start Trigger Bit A</p> <p>FB Busy Flag Bit B</p> <p>Master Unit number &10</p> <p>Slave node address &11</p> <p>Regularly read the status of the Sensor Amplifier's Communication Unit.</p> <p>Communications Error with Sensor Bit E</p> <p>Processing when a sensor communications error occurred</p> <p>_ExxDRT207_ReadStatus</p> <table border="0"> <tr> <td>(BOOL)</td> <td>ENO</td> <td>(BOOL)</td> <td>FB Busy Flag Bit B</td> </tr> <tr> <td>(INT)</td> <td>MasterUnitNo</td> <td>(BOOL)</td> <td>FB Normal End Bit C</td> </tr> <tr> <td>(INT)</td> <td>NodeNo</td> <td>(BOOL)</td> <td>FB Error End Bit D</td> </tr> <tr> <td></td> <td></td> <td>(BOOL)</td> <td>Communications Error with Sensor Bit E</td> </tr> <tr> <td></td> <td></td> <td>(BOOL)</td> <td>Communicating with Sensor Bit F</td> </tr> <tr> <td></td> <td></td> <td>(BOOL)</td> <td>Communicating with Mobile Console Bit G</td> </tr> </table>	(BOOL)	ENO	(BOOL)	FB Busy Flag Bit B	(INT)	MasterUnitNo	(BOOL)	FB Normal End Bit C	(INT)	NodeNo	(BOOL)	FB Error End Bit D			(BOOL)	Communications Error with Sensor Bit E			(BOOL)	Communicating with Sensor Bit F			(BOOL)	Communicating with Mobile Console Bit G
(BOOL)	ENO	(BOOL)	FB Busy Flag Bit B																						
(INT)	MasterUnitNo	(BOOL)	FB Normal End Bit C																						
(INT)	NodeNo	(BOOL)	FB Error End Bit D																						
		(BOOL)	Communications Error with Sensor Bit E																						
		(BOOL)	Communicating with Sensor Bit F																						
		(BOOL)	Communicating with Mobile Console Bit G																						
<p>Related manuals</p>	<p>Communication Unit For Digital Fiber Sensor E3X-DRT21-S (DeviceNet) (Z223-E1)</p> <p>CS/CJ Series Communications Commands Reference Manual (W342-E1) 5-1 Command Lists</p>																								

Variable Tables**Input Variables**

Name	Variable name	Data type	Default	Range	Description
EN	EN	BOOL			1 (ON): FB started 0 (OFF): FB not started.
Master Unit No.	MasterUnitNo	INT	&0	&0 to &15 � to &#F	Specify the unit number of the DeviceNet Unit.
Slave node address	NodeNo	INT	&0	&0 to &63	Specify the node address of the slave.

Output Variables

Name	Variable name	Data type	Range	Description
ENO (May be omitted.)	ENO	BOOL		1 (ON): FB processed normally. 0 (OFF): FB not processed or ended in an error.
FB Busy Flag	FB_BUSY	BOOL		Automatically turns OFF when processing is completed.
FB Normal End	FB_OK	BOOL		Turns ON for one cycle when processing ends normally.
FB Error End	FB_NG	BOOL		Turns ON for one cycle when processing ends in an error.
Communications Error with Sensor	SensorComError	BOOL		Turns ON in the following cases: 1. The maximum number of sensors setting does not match the number of sensors that can actually communicate. 2. There is a communications error after communications were established with a sensor.
Communicating with Sensor	Communicating	BOOL		Turns ON when communications have been established with the Sensor.
Communicating with Mobile Console	MCCCommunicating	BOOL		Turns ON when a Mobile Console is connected. Communications will not be possible when a Mobile Console is connected.

Internal Variables

Internal variables are not output from the FB.

If the FB_NG Flag turns ON, the following internal variables can be monitored to obtain information on the error.

Name	Variable name	Data type	Range	Description
FINS error code	FINS_ErrorCode	WORD		The FINS error code is output. A code of #0000 is output for a normal end. Refer to the <i>Related Manuals</i> for details on the error codes.
Explicit message error code	Explicit_ErrorCode	WORD		Outputs the explicit message error code. A code of #0000 is output for a normal end. Refer to the <i>Related Manuals</i> for details on the error codes.

Explicit Error Code Details

Code	Contents	Meaning
#0000	Normal end	---
#16FF	No Sensor Amplifier	There is no Sensor Amplifier with the specified unit number.
#0CFF	Not executable	The specified command cannot be executed. <ul style="list-style-type: none"> • A Mobile Console is connected. • There is an error in communications with the Sensor Amplifier. • The Sensor Amplifier is in an operation mode other than RUN mode. • The FB was executed for a Sensor Amplifier that is not supported.

Version History

Version	Date	Contents
1.00	2005.4.	Original production

Note

This manual is a reference that explains the function block functions.

It does not explain the operational limitations of Units, components, or combinations of Units and components. Always read and understand the Operation Manuals for the system's Units and other components before using them.