

ZXLN 010	Teach 2-point High Thresholds: _ZXLN010_Teach2HighThreshold
---------------------	--

Basic function	Uses two points to teach the high threshold.								
Symbol									
File name	Lib\FBL\omronlib\LaserSensor\ZXLN_ZXLN010_Teach2HighThreshold10.cxf								
Applicable models	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Smart Sensor</td> <td>ZX-LDA-N</td> </tr> <tr> <td>CPU Unit</td> <td>CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher CP1H CP1L (except 10 points CPU)</td> </tr> <tr> <td>Serial Communications Units/Boards</td> <td>CS1W-SCU21-V1, CJ1W-SCU21-V1, CJ1W-SCU41-V1 Unit Version 1.2 or higher CS1W-SCB21-V1 and CS1W-SCB41-V1 Unit Version 1.2 or higher</td> </tr> <tr> <td>CX-Programmer</td> <td>Version 5.0 or higher</td> </tr> </table>	Smart Sensor	ZX-LDA-N	CPU Unit	CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher CP1H CP1L (except 10 points CPU)	Serial Communications Units/Boards	CS1W-SCU21-V1, CJ1W-SCU21-V1, CJ1W-SCU41-V1 Unit Version 1.2 or higher CS1W-SCB21-V1 and CS1W-SCB41-V1 Unit Version 1.2 or higher	CX-Programmer	Version 5.0 or higher
Smart Sensor	ZX-LDA-N								
CPU Unit	CS1*-CPU**H Unit version 3.0 or higher CJ1*-CPU**H Unit version 3.0 or higher CJ1M-CPU** Unit version 3.0 or higher CP1H CP1L (except 10 points CPU)								
Serial Communications Units/Boards	CS1W-SCU21-V1, CJ1W-SCU21-V1, CJ1W-SCU41-V1 Unit Version 1.2 or higher CS1W-SCB21-V1 and CS1W-SCB41-V1 Unit Version 1.2 or higher								
CX-Programmer	Version 5.0 or higher								
Conditions for usage	<ul style="list-style-type: none"> ■ External Connections <ul style="list-style-type: none"> • Can be used for 1:N connections in the controller configuration of the sensor side. • Communications must be within one network and cannot cross to another network. ■ Communication Settings <p>The communication settings of the serial port (Serial Gateway) must be the same as those of the Smart Sensor.</p> <ul style="list-style-type: none"> • The communications settings of the specified serial port can be set to the default Smart Sensor settings (the factory shipment value) using the <i>Set Communications Port</i> (_ZXL600_SetComm) function block, and the other Smart Sensor settings using the <i>Set Serial Gateway Mode</i> (_SCx604_SetPortGATEWAY) function block. ■ CPU Unit Settings <p>PC System Setup: <i>Shared Settings for Communications Instructions in FBs.</i></p> <ul style="list-style-type: none"> • Communications Instruction Response Timeout Time (default: 2 s), 5 s or more is recommended. • Number of retries (default: 0) ■ Shared Resources <ul style="list-style-type: none"> • Communications ports (Internal logical ports) 								
Function description	<p>When the <i>Start Trigger</i> turns ON, the high threshold is taught using 2 points for the Smart Sensor connected to the Serial Port specified by the <i>Connection unit</i>, <i>Serial port No</i> and <i>Sensor CH No.</i>.</p> <p>This FB sets the intermediate value between the current value of the main digital display and the current low threshold value as the low threshold.</p> <p>An execution error will occur if the display value is not being held or if the low threshold is higher than the high threshold.</p>								
FB precautions	<ul style="list-style-type: none"> • This FB is processed over multiple cycles. The BUSY output variable can be used to check whether the FB is being processed. • OK or NG will be turned ON only for one cycle after processing is completed. Use these flags to detect the end of the FB processing. <p>Time Chart</p>								
EN input condition	Connect EN to an OR between an upwardly differentiated condition for the <i>Start Trigger</i> and the BUSY output from the FB as above.								
Restrictions Input variables	<ul style="list-style-type: none"> • Always use an upwardly differentiated condition for EN. • If the input variables are out of range, the ENO Flag will turn OFF and the FB will not be processed. 								
Output variables	<ul style="list-style-type: none"> • This FB requires multiple cycles to process. Always connect an OR including the BUSY output variable to the EN input variable to ensure that the FB is processed to a completion (see <i>Symbol</i>). • Do not turn the BUSY output variable ON or OFF outside the FB. 								

<p>Other</p>	<ul style="list-style-type: none"> • 3 seconds or more may be required for this FB to be completed (i.e., from EN turning ON until the OK or NG Flag turns ON).
<p>Application example</p>	<p>Smart Sensor is connected 1:N to the Serial Port 1 on the Serial Communications Board (SCB). When bit A turns ON, the high threshold is taught using two points.</p> <p>The diagram illustrates the hardware and logic for the <code>_ZXLN010_Teach2HighThreshold</code> function block. The PLC rack consists of an SCB (Serial Communications Board), CPU, and SCU. A Smart Sensor CH1 is connected to the SCB via a 1:N connection. The ladder logic shows Bit A (normally open) and Bit B (normally closed) connected to the <code>Unit Selection #BBBB</code> input. Bit C (normally open) is connected to the <code>Processing for Operation Commands</code> block. The function block outputs <code>Busy Flag</code> (Bit B), <code>Normal End</code> (Bit C), <code>Error End</code> (Bit D), and <code>NG</code>.</p>
<p>Related manuals</p>	<p><i>ZX-L-N Series Smart Sensor Laser Type User's Manual (SCHE-703)</i> <i>ZX Series Smart Sensor Operation Manual (SCEA-801)</i></p>
<p>Related FBs</p>	<p><i>Teach 1-point High Threshold</i> (<code>_ZXLN008_Teach1HighThreshold</code>) <i>Teach 1-point Low Threshold</i> (<code>_ZXLN009_Teach1LowThreshold</code>) <i>Teach 2-point Low Threshold</i> (<code>_ZXLN011_Teach2LowThreshold</code>)</p>

■ Variable Tables

Input Variables

Name	Variable name	Data type	Default	Range	Description												
EN	EN	BOOL			1 (ON): FB started. 0 (OFF): FB not started.												
Unit selection Serial Port No.	UnitSelect PortNo	INT INT	&0 &1	As right &1 to &2	Specify the Unit and the serial port. Only serial port 2 of CP1H/CP1L M-type CPU unit is possible to use this FB. <ul style="list-style-type: none"> ■ Connected to CPU Unit <table style="margin-left: 20px;"> <tr><td>Unit selection</td><td>#FFFF</td></tr> <tr><td>Serial port No.</td><td>Not accessed. (CP1H/CP1L-M: Serial Port2 CP1L-L14/20: Serial Port1)</td></tr> </table> ■ Connected to Serial Communication Board(SCB) <table style="margin-left: 20px;"> <tr><td>Unit selection</td><td>#BBBB</td></tr> <tr><td>Serial port No.</td><td>&1: Serial Port 1 &2: Serial Port 2</td></tr> </table> ■ Connected to Serial Communication Unit(SCU) <table style="margin-left: 20px;"> <tr><td>Unit selection</td><td>SCU Unit No. (&0 to &15)</td></tr> <tr><td>Serial port No.</td><td>&1: Serial Port 1 &2: Serial Port 2</td></tr> </table> 	Unit selection	#FFFF	Serial port No.	Not accessed. (CP1H/CP1L-M: Serial Port2 CP1L-L14/20: Serial Port1)	Unit selection	#BBBB	Serial port No.	&1: Serial Port 1 &2: Serial Port 2	Unit selection	SCU Unit No. (&0 to &15)	Serial port No.	&1: Serial Port 1 &2: Serial Port 2
Unit selection	#FFFF																
Serial port No.	Not accessed. (CP1H/CP1L-M: Serial Port2 CP1L-L14/20: Serial Port1)																
Unit selection	#BBBB																
Serial port No.	&1: Serial Port 1 &2: Serial Port 2																
Unit selection	SCU Unit No. (&0 to &15)																
Serial port No.	&1: Serial Port 1 &2: Serial Port 2																
Sensor CH No.	SensorChNo	INT	&1	&1 to &5	Specify the CH No. of the connecting sensor. e.g.: &2 in the case of CH2.												

Output Variables

Name	Variable name	Data type	Range	Description
ENO (May be omitted.)	ENO	BOOL		1 (ON): FB processed normally. 0 (OFF): FB not processed or ended in an error.
Busy Flag	BUSY	BOOL		Automatically turns OFF when processing is completed.
Normal end	OK	BOOL		Turns ON for one cycle when processing ends normally.
Error end	NG	BOOL		Turns ON for one cycle when processing ends in an error.

Internal Variables

Internal variables are not output from the FB.

If the NG Flag from the FB turns ON, the following internal variables can be monitored to obtain information on the error.

Name	Variable name	Data type	Range	Description
Error code	ErrorCode	WORD		The results information from the Smart Sensor is output to the Error Code.

Error Code Details

Code	Contents	Meaning
#0000	Normal end	
#2203	Operation error	The setting is incorrect. Refer to the <i>ZX Series Smart Sensor Operation Manual</i> for the setting error conditions of teaching or the zero reset function.
#2204	Operation error	The sensor's operation mode is not in the RUN mode.

Version History

Version	Date	Contents
1.00	2005.12.	Original production

Note

This manual is a reference that explains the function block functions.

It does not explain the operational limitations of Units, components, or combinations of Units and components. Always read and understand the Operation Manuals for the system's Units and other components before using them.